

Exiting Setup

ROM ISA BIOS (2.14/2000) CMOS SETUP UTILITY AWARD SOFTWARE, INC.	
STANDARD CMOS SETUP	SET CMOS PASSWORD
BIOS FEATURES SETUP	SET POWER ON PASSWORD
CHIPSET FEATURES SETUP	IDE HDD AUTO DETECTION
POWER MANAGEMENT SETUP	SAVE AND EXIT SETUP
LOAD BIOS DEFAULTS	EXIT WITHOUT SAVING
LOAD SETUP	SAVE TO CMOS and EXIT (Y/N)? Y
Esc : Quit	↑ ↓ → ← : Select Item
F10 : Save and Exit Setup	(Shift) F2 : Change Color
SAVE DATA TO CMOS and EXIT SETUP	

After you have made changes under Setup, press <Esc> to return to the main menu. Move cursor to "Save and Exit Setup" or press "F10" and then press "Y" to change the CMOS Setup. If you did not change anything, press <Esc> again or move cursor to "Exit Without Saving" and press "Y" to retain the Setup settings.

→ **NOTE : Default values of the various Setup items on this chapter may not necessarily be the same ones shown on your screen.**

486-GIO-VP

Hard Disk Specifications

This appendix contains some technical information about the different IDE hard disks drives which can be installed with your 486-GIO-VP motherboard.

CONNER

MODEL	CAPACITY	CYLINDER	HEAD	SECTOR
CP-30104	120MB	726	8	39
CP-30174	170MB	903	8	46
CP-30204	200MB	683	16	38
CP-30254	251MB	895	10	55
CP-30344	343MB	904	16	46
CP-30364	360MB	702	16	63
CP-30544	544MB	1024	16	63

MAXTOR

MODEL	CAPACITY	CYLINDER	HEAD	SECTOR
7120A	120MB	1023	14	17
7170A	170MB	984	10	34
7213A	213MB	683	16	38
7245A	245MB	967	16	31
7345A	345MB	790	15	57

QUANTUM

MODEL	CAPACITY	CYLINDER	HEAD	SECTOR
LPS120AT	120MB	901	5	53
LPS240AT	240MB	723	13	51
ELS127AT	127MB	919	16	17
ELS170AT	170MB	1011	15	22

486-GIO-VP