

TOTAL MEMORY	SIMM 1 BANK 0 (72-PIN)	SIMM 2 BANK 1 (72-PIN)	SIMM 3 BANK 2 (72-PIN)	SIMM 4 BANK 3 (72-PIN)
17MB	16MB	1MB		
18MB	16MB	1MB	1MB	
19MB	16MB	1MB	1MB	1MB
20MB	16MB	4MB		
21MB	16MB	4MB	1MB	
22MB	16MB	4MB	1MB	1MB
24MB	16MB	4MB	4MB	
28MB	16MB	4MB	4MB	4MB
32MB	16MB	16MB		
			32MB *	
33MB	16MB	16MB	1MB	
34MB	16MB	16MB	1MB	1MB
36MB	16MB	16MB	4MB	
40MB	16MB	16MB	4MB	4MB
48MB	16MB	16MB	16MB	
		16MB	32MB *	
			16MB	32MB *
64MB	16MB	16MB	16MB	16MB
		16MB	32MB *	16MB
			32MB *	32MB *

* Double-RAS SIMM

Table 3-1. DRAM Configurations

→ **NOTE : Only Bank 2 (SIMM 3) and Bank 3 (SIMM 4) supports Double-RAS SIMM.**

Installation Instructions

→ **NOTE : Always observe static electricity precautions. See "Handling Precautions" at the start of this manual.**

1. Locate the SIMM banks on the mainboard. Determine your desired configuration to be installed.